

OPEN FIRST!!

Parts list for Master set # 3-18121

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start.**

Transmission mount:

- 1 - 1036 mount
- 1 - 15.810 backing plate
- 2 - 15.348 (7/16" lockwasher)
- 4 - 15.342 (7/16" flat washer)
- 2 - 15.530 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front control arm bushing set:

- 4 - "E" shells
- 4 - 3001 bushings (upper control arm)
- 4 - 15.011 (13/16" O.D. x .675" I.D. x 1.562" sleeve)
- 4 - "J" shells
- 4 - 3002 bushing (lower control arm)
- 4 - 15.184 (7/8" O.D. x 3/4" I.D. x 1.90" sleeve)
- 1 - 17019 installation instructions

Body mount set:

- 2 - 4057 bushings (top, position #1)
- 14 - 4038 bushings (top, all other positions)
- 16 - 4039 bushings (bottom, all positions)
- 16 - 15.082 (7/8" O.D. X 3/4" I.D. X 1.060" sleeve)
- 16 - 15.306 (2" O.D. x 3/8" I.D. washer, bottom, all positions)
- 2 - 15.315 (1-3/4" x 2-1/2" x 3/8" washer, top, position #1)
- 14 - 15.308 (2-1/2" O.D. x 3/8" I.D. washer, top, all other positions)
- 1 - 17014 installation instructions

Rear leaf spring bushing set:

- 1955 vehicles use the following
- 12 - 2068 leaf spring and shackle bushings
 - 2 - 15.030 (5/8" O.D. x 1/2" I.D. x 2.562" sleeve)
use this sleeve in the main eye
 - 1 - 17040 installation instructions

1956-57 vehicles use the following

- 8 - 2068 leaf spring bushings
- 2 - 15.030 (5/8" O.D. x 1/2" I.D. x 2.562" sleeve)
use this sleeve in the main eye
- 4 - 2069 frame shackle bushings
use 17040 installation instructions



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts list continued:

Front sway bar endlink set:

- 8 - 4806 endlink grommets
- 8 - 15.301 (cupped washer)
- 2 - 15.021 (9/16" O.D. x 3/8" I.D. x 2.6" sleeve)
- 2 - 15.504 (3/8"-16 x 7" bolt)
- 2 - 15.701 (3/8"-16 nut)

Tie-rod boot set:

- 4 - 13001 tie-rod boots

Grease:

- 2 - 9.11101 grease tubs

Additional parts available

V8 motor mount grommet set: Set # 3-1102

UNIVERSAL/MULTI. APP. SWAY BAR BUSHING SET NUMBERS

Greasable Set #	Sway Bar Diameter	Non-Greasable Set #
9-5151	7/16"	9-5101
9-5152	1/2"	9-5102
9-5153	9/16"	9-5103
9-5154	5/8" (16mm)	9-5104
9-5155	11/16"	9-5105
9-5156	3/4" (19mm)	9-5106
9-5157	13/16"	9-5107
9-5158	7/8" (22mm)	9-5108
9-5159	23mm	9-5115
9-5160	15/16" (24mm)	9-5109
9-5161	1"	9-5110
9-5162	1 1/16"	9-5111
9-5163	28mm	9-5130
9-5164	1 1/8"	9-5112
9-5165	1 1/4"	9-5113
9-5166	32mm	9-5116
9-5167	1 5/16"	9-5114
9-5168	1 3/8"	9-5136

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see our catalog at your place of purchase.

© 2002 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.